



**OUR PRODUCT IS  
TWICE AS STRONG!  
COMPARE COST &  
EFFECTIVENESS!**



**ACID WASH  
THE BIO-DEX WAY!**

**NO DRAIN  
DEEP CLEAN**

**STEP 1 - PREP**

1. Before Draining: (keep swimmers out during the process)
  - Raise the waterline above any scale, dirt or slime along the tile line
  - Pour 1 gallon Bio-Dex **Protect-All Supreme** per 10,000 gallons into the water and allow to circulate for 24 to 48 hours.
2. Drain the water according to city regulations and builder recommendations.

**STEP 2 - THE MIX**

- Using a 5 gallon bucket.
1. Pour in two gallons water (warm water if very cold for easier mixing)
  2. Pour in one gallon acid
  3. Pour in 8 oz **Plaster White 'n Brite** (may be used for all colors and types of pool surfaces including black plaster)
  4. Pour in 8 oz **Aquadex 50 Stain-Off**
  5. Blend, using something like a paint mix stick.

**STEP 3 - THE WASH**

- Garden Sprayers may be used but the mix may need to be adjusted for ease of use
6. Standing on the deck, at the edge of the pool, pour the mixture down the side. Continue around the perimeter until completion. Scrubbing is optional at this time.
  7. With a hose, begin rinsing at the initial starting point and continue to rinse all the way around the pool.
  8. Pump or drain excess residual. Use Bio-Dex **Foam Stop** if excess foam is a problem.

**STEP 4 - START UP**

- All doses per 10,000 gallons**
- Refill the pool adding 6oz of **Protect-All Supreme** in thirds as the pool fills. (total 18 oz)
  - Balance the pool water as needed
  - Add 2 oz **Clearex 500** to the skimmer when the filter is turned on.

**STEP 5 - MAINTENANCE**

- NOTE:** Smaller does can be added weekly
- Add 6 oz **Protect-All Supreme** monthly
  - Add 6 oz **Aquadex 50 Stain-Off** monthly
  - Add 3 oz **Clearex 500** monthly

**Process below is per 10,000 gallons:**

**NOTE:** Maintain normal chlorine levels throughout the full process

**STEP 1**

- Raise the water line over scale, dirt and soil if possible
- Apply 1 quart **Protect-All Supreme** by pouring around the perimeter of the water.
- Pour 2 oz **Clearex 500 Clarifier** in the skimmer.
- Run the Filter for 24 hours and brush if possible.

**STEP 2**

- Turn off the filter and apply 2 quarts **Aquadex 50 Stain-Off**, pouring in areas where the stains are most severe. Allow to dwell for 4 to 8 hours.

**STEP 3**

- Turn on the filter and run for at least 8 hours

**STEP 4**

- Add 2 more ounces **Clearex 500** and adjust chlorine and ph as needed.
  - Continue to brush for 7 days if possible.
- TIP:** Process can be repeated as needed for maximum results

**STEP 5**

- MONTHLY MAINTENANCE**
- NOTE:** Can be added weekly in smaller amounts
- Add 6 oz **Protect-All Supreme** monthly
  - Add 6 oz **Aquadex 50 Stain-Off** monthly
  - Add 3 oz **Clearex 500 Clarifier** monthly

